

Rigging Plan BOOM-M-110 & BOOM-H-110 Main Boom & Headsail Boom Kits – 11.0 mm diameter round tube for IOM Class 2020

Instruction

- 1 Drill 1.8 mm diameter holes at 5 mm intervals. Both booms.
- 2 Use sheet hook to attach sheet to boom. Both booms.
- 3 Add 'O' rings that keep sheet hook in place. Both booms.
- 4 Add boom band at sheet attachment points. Glue in place. Both booms.
- 5 Add boom band at swivel position. Attach headsail Cunningham. Glue in place. Headsail boom only.
- 6 Add boom band for Cunningham attachment. Glue in place. Main boom only.
- 7 Add boom band, stainless steel, for forestay. Glue in place. Headsail boom only.
- 8 Add clew attachments. Bend the leg forwards to open hook for sail clew. Both booms.
- 9 Add topping lift attachment. Glue in place. Headsail boom only.
- 10 Not provided in kit. Add boom end fitting. Main boom only.
- 11 Add counterbalance weight attachment, ref 101-110. Headsail boom only.
- 12 Not provided in kit. Add counterbalance weight, ref 102-15, and lock in place using screw.

BOOM-M-110 Kit Contents

Code	Qty
48-110	2
82-010	2
87Z	1
105-110	1
AR-110-365	365 mm

BOOM-H-110 Kit contents

Code	Qty
48-110	2
57-120	2
82-010	2
87Z	1
101-110	1
101G-110	1
105-110	1
106-110	1
AR-110-400	400 mm

SAILSetc

141 High Street
Kelvedon
Essex
www.sailsetc2.com
sales@sailsetc.com

England
© May 2020, Graham Bantock

CO5 9AA

